

Bike-Quip: Installation Guidelines – ST1300 Stainless Steel Crash Bars

Note: Please read ALL these instructions before starting the procedure.

It is advised that **ONLY ONE BOLT PER SIDE is removed at any one time**. This is due to the likely movement between the Footrest Hangers and the Rear Sub Frame onto which they are fastened.

It is also advisable to remove the panniers prior to commencing this fitting sequence.

Familiarise yourself with how the Footrest Hangers are bolted onto the Rear Sub Frame with two bolts per side. These bolts will be replaced with the two (longer) bolts provided but should be kept in case the Crash Bars are removed at a future time.

If you decide to use lubricant on the replacement bolts, it is imperative that any excess Hydrocarbon based products **DO NOT** come into contact with the rubber gaskets as this will cause deterioration/deformation of the rubber.

The Adhesive Gaskets (provided) should be affixed to the Crash Bar Mounting Plate. If both bolts are passed through the plate, this will aid the correct orientation of the gasket but bear in mind there will be slight play in the boltholes.

Note: The adhesive side is designed to adhere to the Mounting Plate NOT the Footrest Hangers.

It is advisable to use a spray bottle and weak liquid soap solution to wet both the adhesive surface of the Gasket and the mounting plate. This will allow a slight movement of the gasket to achieve the desired alignment. Once in the correct orientation, the water can then be displaced by use of a straight edge such as a credit card (overwrapped with a cloth). This will allow full contact of the adhesive and set the gasket in place. We recommend allowing 10 minutes for the adhesive to set.

Once the Gaskets are firmly attached in the desired position, using an 8mm Allen Key, ONE BOLT can be removed from the Footrest Hanger. The Crash Bar can then be offered up 'skewed' whilst the replacement bolt (supplied) is fitted – INSERT ONLY 95% and ensure the Crash Bar can still rotate around this first bolt in order to allow second bolt to be removed.

Note: If for whatever reason lubricant is used on the outer rubber surface then any such lubricant **MUST be RUBBER Compatible** and **NOT HYDROCARBON based** as this will cause the gaskets to deteriorate over time.

Remove the second bolt, rotate the Crash Bar into its final position and then fit the second (replacement) bolt.

Fully tighten both bolts – **Haynes Manual states 42Nm (31ft lb)**

PLEASE – do not rush any aspect of the fitting procedure. Take great care throughout.

Note: You will notice there is a slight restriction when opening the pannier to its full extent as dictated by the original retainer strap. It is still possible to open to that full extent by careful manipulation of the forward end of the pannier lid against the outer end of the crash bar. This was incorporated into the design and provides less interference with pillion foot positioning than having the crash bar mounted any further forward.

Ride Safe!